

Oscar Trek Item List



Receiver with Basic Accessories



1 x Oscar Trek GNSS Receiver
598001 / 597003(TAP)



2 x BN20 Battery
501003



1 x CN20 Charger
502003



1 x CN20 Charger Adapter
503000



1 x CN20 Charger Adapter Cable (A / B / C / E / N / I)^[1]
505(A) 507(B) 506(C) 504(E) 508(N) 560(I)



1 x 450-470MHz Radio Whip Antenna^[2]
588000



1 x Mini-USB Cable
524000



1 x Mini-USB OTG Cable
159000



1 x Carrying Case for Oscar Rover
580000(TC40) / 564000(TC80)



1 x Warranty Card
ACC023



1 x Quick Start Guide

TC40 Controller Kit



1 x TC40 Controller
567002



1 x Type-C USB Cable for TC40
587000



1 x Stylus Pen for TC40
574000



1 x Bracket for TC40
572000



(EU)



(US)



(UK)



(AU)

1 x TC40 Charger Adapter
582(EU)/ 584(US)/ 585(UK)/ 586(AU)



1 x TC40 Controller Hand
Strap & Screws & Screw Wrench
567002

TC80 Controller Kit



1 x TC80 Controller
611003



1 x Type-C USB Cable
587000



(A)

(B)

(N)

(E)

1 x TC80 Charger Adapter Plug ^[1]
534(A)/ 536(B)/ 537(N)/535(E)



1 x Bracket for TC80
612000

Standard Rover Accessories



1 x Ranging Pole with Bag
605000

Optional Accessories Configuration Cable for Oscar Trek



1 x Serial-5pin to DC JACK &
DB9 Male Cable
157000



1 x 2m DC JACK Male
169002



1 x 2m DC JACK Male
with Alligator Clip
371000



1 x DB9 Female to USB Type A
Male Converter Cable
317000

[1] The model of the cable will be delivered according to customer requirements.

A: American, B: British, C: Chinese, E: European, N: Australian, I: Italy

[2] Optional antennas: 410-430 MHz (588010), 430-450 MHz (588030), 410-470 MHz (513000).