

Nuwa Version(2.4.5.0) Release

June 15, 2023

Overview

Tersus GNSS Inc. ("Tersus") is glad to release the Nuwa for GNSS receiver. Nuwa version (2.4.5.0) is available to download at <u>www.tersus-gnss.com/software/software</u> and support documents are available at <u>www.tersus-gnss.com/document/software</u>.

Features

- Assists with Bluetooth/USB connection
- Configure base/rover setup
- Visualized interface for receiver operations
- Data management (import/export)

Change from Previous Versions

| Issue | Туре | Version |
|---|---------------|---------|
| Added the ability to automatically download | | |
| when the coordinate system selected in new | Enhancement | |
| project contains missing grid and geoid files. | | |
| Added the judgment and pormpt if there are | Enhancement | |
| points with the same name in Point Import. | Emancement | |
| Adjusted the interface of road input and added | Enhancement | |
| the road preview function. | Emancement | |
| Added controller voice broadcast function. | Enhancement | |
| Added Base info tab page in the location | | |
| screen, displaying information including base | Enhancement | |
| power, base satellite count and format. | | |
| Added base abnormal movement alert. | Enhancement | |
| Added the function of measuring when the tilt | Enhancement | 2450 |
| compensation fails but the pole is vertical. | Emancement | 2.4.5.0 |
| Added KLIC XML vector map format support | Enhancement | |
| and related color display. | Emancement | |
| When Stakeout prompt type is set to North | | |
| and south direction, adjusted the blue arrow | Enhancement | |
| to be North-South. | | |
| Added the coordinate display when selecting | Fabaaament | |
| the staking points. | Enhancement | |
| Added the configuration of displaying survey | Fahanaanaarat | |
| and stakout points in the line stakeout screen. | Enhancement | |
| Added the choice of calculating L from A or | Enhancement | |
| from B in the tool Offset Point From Line. | | |
| Added Kazakhstan predefined coordinate | Enhancement | |

| system, modified Turkey, South Africa | | |
|---|-------------|---------|
| predefined coordinate system. | | |
| Added Bosnian, updated German. | Enhancement | |
| Fixed the issue that RTCM1021, 1023, 1025 check configuration may not be saved. | Bug Fix | |
| Fixed the issue that APP shortcut keys on controller may repeatedly start the software. | Bug Fix | |
| Fixed the issue that the distance calculation to the base may be wrong. | Bug Fix | |
| Added support for LUKA connection. | Enhancement | |
| Added support for David30-D connection. | Enhancement | |
| Added the zone number setting for Gauss Krueger 3-degree zone projection. | Enhancement | |
| Optimized the login and registration interface of Tersus Cloud service. | Enhancement | |
| Added the AR mode in Point Stakeout. | Enhancement | |
| Added support for importing PHI road format. | Enhancement | |
| Added TIN Display setting in Surface Stakeout. | Enhancement | |
| Added Record Antenna Type configuration in Static Survey. | Enhancement | 2.4.4.0 |
| Added the export of RAW format. | Enhancement | |
| Added export content for HTML and RW5. | Enhancement | |
| Updated predefined CRS of Oman, Switzerland, | Enhancement | |
| Germany, Russia and El Salvador. | | |
| Updated Spanish, French, Dutch display. | Enhancement | |
| Fixed the problem that the data initialization | | |
| may fail in Survey and Stakeout interface with larger geoid files. | Bug Fix | |
| Fixed the problem that static parameters | Bug Fix | |

| cannot be modified after recording stopped. | | |
|--|--------------------|---------|
| Fixed the problem that the antenna type is | Bug Fix | |
| incorrect in David30 static survey. | | |
| Fixed the problem that the tilt data bar was | | |
| not cleared after turning off the tilt. | Bug Fix | |
| Fixed the problem that Dis to Base in the data | 5 5 | |
| bar was incorrect when the unit is feet. | Bug Fix | |
| Fixed the problem that Miles in the data bar | | |
| was incorrect in Line Stakeout with offset. | Bug Fix | |
| Fixed the crash in searching or selecting survey | | |
| points when manually starting base mode or | Bug Fix | |
| creating staking lines. | | |
| Fixed the problem that the default export | | |
| format could not be separated automatically | Bug Fix | |
| with Excel in European region. | | |
| Fixed the crash of Azimuth Distance when the | | |
| angle format is DMS. | Bug Fix | |
| Fixed the problem that opening CAD drawings | Bug Fix | |
| may fail on Android 11 and above. | Bug Fix | |
| Fixed the problem that it may take a long time | | |
| to start the software on Android 11 and above. | Bug Fix | |
| Fixed the problem of incomplete display in | Pug Fix | |
| main page in some languages. | Bug Fix | |
| Added configuration of projection height | Enhancoment | |
| parameters. | Enhancement | |
| Added the function of IMU calibration when | Enhancoment | 2220 |
| connecting Oscar Ultimate. | Enhancement | 2.3.3.0 |
| Added coordinates display of selecting points | Fabra and a | |
| in CAD Stakeout. | Enhancement | |
| | 1 | |

| Added the function of selecting points from | |
|---|-------------|
| survey point list and control point list in Point | Enhancement |
| Stakeout. | |
| Added loc file import function in Site | |
| | Fahanaant |
| Calibration, added selecting points to | Enhancement |
| participate in the calculation. | |
| Added code attribute to control point and | Enhancement |
| staking point. | |
| Added a guide interface when starting the | Enhancement |
| software for the first time. | |
| Added icon editing mode. | Enhancement |
| Improved the speed of online updata, added | Enhancement |
| download progress display. | |
| Updated Spanish, Russian and French. | Enhancement |
| Added Tersus Cloud (beta version), including | |
| the function of one-click synchronization, | Enhancement |
| project and data file upload and download. | |
| Fixed the issue of disconnection when no | |
| positioning data is received when connecting | Bug Fix |
| to Oscar. | |
| Fixed the issue that the antenna type may be | |
| deleted abnormally. | Bug Fix |
| Fixed the issue that Google online map may | |
| not be displayed in the Survey and Staekout | Bug Fix |
| interface. | |
| Fixed the issue that the calculation of Oblique | |
| Mercator Projection may not be correct. | Bug Fix |
| Fixed the issue of crashing after exporting and | |
| | Bug Fix |
| clicking share. | |

| Added millimeter unit setting and optimized | | |
|---|-----------------------|---------|
| the display of drawing in CAD Stakeout. | Enhancement | |
| Added cross section export format and fixed | | |
| the problem of incorrect display of offsets. | Enhancement | |
| Fixed the issue that the cut or fill value | Due Civ | 2.3.2.2 |
| calculated in Line Stakeout may be incorrect. | Bug Fix | |
| Fixed crash when searching for staking points | Dug Eiv | |
| and inability to select search results. | Bug Fix | |
| Optimized the display of Spanish language. | Bug Fix | |
| Added the import of LandXML, KML, KMZ | Enhancement | |
| vector maps. | Linancement | |
| Added support for importing LandXML triangle | | |
| network and selecting points to create a plane | Enhancement | |
| or triangle network in Surface Stakeout. | | |
| Added support for importing LandXML | Enhancement | |
| alignment in Road Stakeout. | | |
| Added point name increment setting in Survey. | Enhancement | |
| Added the code display setting in Survey. | Enhancement | |
| Added staking by nearby for polylines and arcs. | Enhancement | 2.3.2.0 |
| Added support for 3dpolyline in CAD Stakeout. | Enhancement | 2.3.2.0 |
| Added the output of code in RW5 export. | Enhancement | |
| Added the function of switching format when | Enhancement | |
| inputting angle value in Tools. | Emancement | |
| Adjusted the order of the project list display, | Enhancement | |
| sorted by the recent open time. | Enhancement | |
| Added the display of release note when | Enhancement | |
| receiving update. | Enhancement | |
| Added the configuration of whether to apply | F abra and the | |
| RTCM1021-1027 to the current project CRS. | Enhancement | |

| Added Cambodia, Estonia predefined |
|---|
| coordinate system. |
| Fixed the US predefined coordinate system. Enhancement |
| Optimized the performance of vector map loading. Bug Fix |
| Fixed the issue in Android 11 where Bluetooth |
| scanning could fail without location services Bug Fix turned on. |
| Fixed the issue that the antenna type may be |
| empty and the issue that the elevation may be wrong after editing the point when connecting |
| to David. |
| Fixed the issue that when the Survey with confirmation is not turned on, the stake point may not be stored in line stakeout, the antenna parameters may be displayed incorrectly in point detail and the PPK survey may repeat the collection point. |
| Fixed the issue that the offset may be displayed as negative in Point Stakeout. |
| Solved the problem of incorrect filling and cutting value calculated beyond the line range in Line Stakeout. |
| Fixed the issue that the calculation of France Bug Fix gsb format grid is incorrect. |
| Added a progress bar when refreshing the Bug Fix database to avoid app crashes. |
| Added the horizontal display mode for TC40. Enhancement |

| Added Code module, and added the function of selecting code to switch point survey and line survey in Survey interface.EnhancementAdded the tilt entrance in Survey interface.EnhancementAdded the function of selecting staking points to stake in CAD Stakeout.EnhancementAdded the function of switching three RTK working modes.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted low-resolution Geoid/Grid calculations.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle points using custom fields may cause a crash.Bug FixAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | | | |
|--|--|-------------|--|
| line survey in Survey interface.EnhancementAdded the tilt entrance in Survey interface.EnhancementAdded the function of selecting staking points to stake in CAD Stakeout.EnhancementAdded the function of switching three RTK working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted low-resolution Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | Added Code module, and added the function | | |
| Added the tilt entrance in Survey interface.EnhancementAdded the function of selecting staking points to stake in CAD Stakeout.EnhancementAdded the function of switching three RTK working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted low-resolution Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | of selecting code to switch point survey and | Enhancement | |
| Added the function of selecting staking points to stake in CAD Stakeout.EnhancementAdded the function of switching three RTK working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | line survey in Survey interface. | | |
| to stake in CAD Stakeout.EnhancementAdded the function of switching three RTK working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIInvalie | Added the tilt entrance in Survey interface. | Enhancement | |
| to stake in CAD Stakeout.EnhancementAdded the function of switching three RTK working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted low-resolution Geoid/Grid calculations.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIEnhancement | Added the function of selecting staking points | Enhancomont | |
| working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIEnhancement | to stake in CAD Stakeout. | Emancement | |
| working modes.EnhancementAdded RW5 export.EnhancementAdded Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIEnhancement | Added the function of switching three RTK | | |
| Added Indonesia predefined CRS.EnhancementFixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | working modes. | Enhancement | |
| Fixed the issue that the result may be wrong after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIWIFI | Added RW5 export. | Enhancement | |
| after multiple Base Shift calculation and application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | Added Indonesia predefined CRS. | Enhancement | |
| application.Bug FixSolved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | Fixed the issue that the result may be wrong | | |
| Solved the problem of frequently prompted Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | after multiple Base Shift calculation and | Bug Fix | |
| Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | application. | | |
| Invalid Geoid/Grid.Bug FixFixed the issue that there may be bias in some low-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | Solved the problem of frequently prompted | | |
| Iow-resolution Geoid/Grid calculations.Bug FixFixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIEnhancement | Invalid Geoid/Grid. | Bug Fix | |
| Iow-resolution Geoid/Grid calculations.Fixed the issue that the Tilt Angle was displayed as negative when the tilt angle exceeded 90°.Bug FixFixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.Enhancement | Fixed the issue that there may be bias in some | | |
| displayed as negative when the tilt angle Bug Fix exceeded 90°. Fixed the issue that exporting the staking points using custom fields may cause a crash. Added the function of taking a photo in survey confirmation box. Added the function of offset in line stakeout. Enhancement Added the function of displaying the list of the nodes after selecting the line in CAD stakeout. Added the configuration of static IP in WIFI | low-resolution Geoid/Grid calculations. | Bug Fix | |
| exceeded 90°. Fixed the issue that exporting the staking points using custom fields may cause a crash. Added the function of taking a photo in survey confirmation box. Added the function of offset in line stakeout. Added the function of offset in line stakeout. Added the function of displaying the list of the nodes after selecting the line in CAD stakeout. Added the configuration of static IP in WIFI | Fixed the issue that the Tilt Angle was | | |
| Fixed the issue that exporting the staking points using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIEnhancement | displayed as negative when the tilt angle | Bug Fix | |
| Bug FixPoints using custom fields may cause a crash.Bug FixAdded the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIEnhancement | exceeded 90 $^\circ$. | | |
| points using custom fields may cause a crash.Added the function of taking a photo in survey confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIIP in WIFI | Fixed the issue that exporting the staking | Bug Fix | |
| confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFI | points using custom fields may cause a crash. | | |
| confirmation box.EnhancementAdded the function of offset in line stakeout.EnhancementAdded the function of displaying the list of the nodes after selecting the line in CAD stakeout.EnhancementAdded the configuration of static IP in WIFIImage: Configuration of static IP in WIFI | Added the function of taking a photo in survey | Enhancoment | |
| Added the function of displaying the list of the nodes after selecting the line in CAD stakeout. Added the configuration of static IP in WIFI | confirmation box. | Emancement | |
| nodes after selecting the line in CAD stakeout. Enhancement Added the configuration of static IP in WIFI | Added the function of offset in line stakeout. | Enhancement | |
| nodes after selecting the line in CAD stakeout. Added the configuration of static IP in WIFI | Added the function of displaying the list of the | Enhancement | |
| | nodes after selecting the line in CAD stakeout. | | |
| Ennancement | Added the configuration of static IP in WIFI | Enhancement | |
| configuration when connecting to Oscar. | configuration when connecting to Oscar. | | |

| Added the function of TCP push in NMEA | Enhancement | |
|---|-------------|---------|
| output when connecting to Oscar. | | |
| Added the display of correction data format | Enhancement | |
| when connecting to Oscar. | | |
| Added South Africa HTML export format. | Enhancement | |
| Added the option of whether to export height | Enhancement | |
| value when exporting DXF file. | Emancement | |
| Added x-y-h and y-x-h coordinate display type. | Enhancement | |
| Added Denmark predefined coordinate system | Enhancement | |
| Added Qatar predefined coordinate system. | Enhancement | |
| Added Slovak predefined coordinate system. | Enhancement | |
| Added support for gsb format Plan Grid files. | Enhancement | |
| Optimized the log records. | Bug Fix | |
| Optimized the calculation of plane grid and | Bug Fix | |
| geoid, added offset value check. | bug Tix | |
| Optimized the survey database storage logic. | Bug Fix | |
| Fixed the issue that DD:MM:SS in exporting csv | Bug Fix | |
| files may not show correctly in excel. | Bug Tix | |
| Optimized the application of RTCM1021-1027. | Bug Fix | |
| Optimized the display of Russian language. | Bug Fix | |
| Added the function of importing data between | | |
| the point lists of Survey Point, Control Point or | Enhancement | |
| Staking Point. | | |
| Added the function of saving the coordinates | | |
| of the base to the point list in the manually | Enhancement | 2.2.9.0 |
| base mode. | | |
| Optimized the display of icons and texts in | Enhancement | |
| Survey interface. | | |
| Optimized the interaction of code input and | Enhancement | |

| displayed the code list in the survey | |
|--|-------------|
| confirmation box. | |
| Added the configuration of Auto Center during | |
| survey in the Survey Config. | Enhancement |
| Added the option of closing and non-closing | |
| when complete the line work in survey. | Enhancement |
| Added the function to stake the nearest point | |
| in the Point Stakeout module. | Enhancement |
| Added the display of dx dy dz to the target in | |
| staking confirmation box, using different colors | Enhancement |
| according to whether exceed the tolerence. | |
| Added the configuration of Auto zoom during | E.L. |
| stakeout in the Survey Config. | Enhancement |
| Added the calculation and display of the | |
| Remain miles in the Line Stakeout and Road | Enhancement |
| Stakeout. | |
| Added the data export of cross-section in Road | Enhancement |
| Stakeout. | Emancement |
| Added the configuration for Auto in Cutoff | Enhancement |
| Angle setting when connecting to Oscar. | Lindicement |
| Added Wifi Setting when connecting to Oscar. | Enhancement |
| Added Lock device setting when connecting to | Enhancement |
| Oscar. | Lindicement |
| Added the reminder of Oscar expiration time. | Enhancement |
| Added Malaysia predefined coordinate system. | Enhancement |
| Added Romania predefined coordinate system. | Enhancement |
| Added Finland predefined coordinate system. | Enhancement |
| Added Salvador predefined coordinate system. | Enhancement |
| Modified the Column Header is checked by | Enhancement |

| default in Export, and displayed the column | | |
|---|-------------|---------|
| header according to language setting. | | |
| Added the function of Oscar firmware version | Enhancement | |
| check. | Linancement | |
| Added the selection of control point survey | Enhancement | |
| type. | | |
| Added PPK auto survey. | Enhancement | |
| Optimized the interaction of point selection in | Enhancement | |
| Point Stakeout. | Lindicement | |
| Optimized the interaction of file opening in | Enhancement | |
| CAD Stakeout. | | |
| Optimized the rules of point selection rules in | Enhancement | |
| Earthwork. | | |
| Optimized the saving logic of points in | Enhancement | |
| Parameters and Point correction. | | |
| Added the Encode selection in Import. | Enhancement | 2.2.8.0 |
| Optimized the solution of RTCM1021-1027 | Enhancement | |
| parameters. | | |
| Added Polish display. | Enhancement | |
| Updated Vietnamese display. | Enhancement | |
| Fixed the problem that points import in BLH | Bug Fix | |
| format may fail. | bug Tix | |
| Fixed the problem that preview function in | Bug Fix | |
| Import may fail. | Bug Tix | |
| Fixed the problem that importing illegal grid | Bug Fix | |
| files may cause a crash. | bug Tix | |
| Fixed the problem that antenna type may fail | Bug Fix | |
| to read when connecting to David. | | |
| Fixed the problem of point name deleting in | Bug Fix | |

| | 1 | |
|--|-------------|---------|
| the text survey interface. | | |
| Fixed the problem that the stakeout indication | | |
| may be offset when the map rotation opening. | Bug Fix | |
| Fixed the problem that the data may not be | | |
| refreshed in Line Stakeout. | Bug Fix | |
| Fixed the problem that closing layers may not | | |
| be successful in CAD Stakeout. | Bug Fix | |
| Fixed the problem that setting antenna height | | |
| may not be successful in Static Survey. | Bug Fix | |
| Added predefined coordinate system of South | | |
| Africa, Peru, Oman, Libya. | Enhancement | |
| Added the function of setting the repeat count | | |
| after each RTK Reset, and the saving of each | Enhancement | |
| result in the control point survey mode. | | |
| Increased the maximum number of code | | |
| characters to 30. | Enhancement | |
| Allowed swithing staking point by directly click | | |
| it on the map when staking points. | Enhancement | |
| Increased the function of cross-section | | 2270 |
| stakeout in the road stakeout module. | Enhancement | 2.2.7.0 |
| Optimized the logic of road stakeout by | | |
| interval and by nearest in the road stakeout | Enhancement | |
| module. | | |
| Increased the search function when selecting | | |
| points in Parameters Calculation, Point | Enhancement | |
| correction and Base Shift. | | |
| Added the map view when selecting the point | F 1 | |
| library in COGO and other functions. | Enhancement | |
| Added Points average calculation tool. | Enhancement | |
| | | |

| Fixed the problem of new project failure when selecting some coordinate systems. | Bug Fix | |
|--|-------------|---------|
| Fixed the problem of the incorrect stakeout prompt when selecting South African coordinate systems. | Bug Fix | |
| Fixed the problem that the default name of stake point may not be automatically stepped in the stakeout function. | Bug Fix | |
| Fixed a possible error in the calculation of road intersection method. | Bug Fix | |
| Fixed the problem that the stake point will incorrectly be added to the point libarary in the area stakeout module. | Bug Fix | |
| Fixed the problem of incomplete display of some information in the interface of Bluetooth pairing and location information. | Bug Fix | |
| Added the mouse selection tool, the explode tool, the background switching function, and optimized the button display in the CAD stakeout module. | Enhancement | |
| Added the graphical display of the filling and cutting instructions in the surface stakeout. | Enhancement | |
| Added the function of entering the point name to select the point when add a stakeout line or in COGO. | Enhancement | 2.2.6.0 |
| Added Oscar host network module status display. | Enhancement | |
| Added Oscar host language setting. | Enhancement | |
| After selecting the coordinate system when | Enhancement | |

| creating a new project , added the step of | | |
|---|---------------------|---------|
| confirming the coordinate parameters. | | |
| Added line segmentation tool. | Enhancement | |
| Added Peru predefined coordinate system and | F . I | |
| added Vietnamese language. | Enhancement | |
| Solved the problem that the road intersection | | |
| method may be calculated incorrectly. | Bug Fix | |
| Solved the problem that the six parameters of | | |
| height parameters fitting may be calculated | Bug Fix | |
| incorrectly and saved with insufficient | bug i k | |
| accuracy. | | |
| Optimized the QR code of project parameters | | |
| sharing, solved the problem of failure of | Bug Fix | |
| scanning QR code. | | |
| Optimized the display of Turkish language | Bug Fix | |
| Added CAD Stakeout module. | Enhancement | |
| Added Area Stakeout module. | Enhancement | |
| Added the function of keeping the base mode | Enhancement | |
| after reboot in manual start base. | Emancement | |
| Added the function of keeping coordinates | Enhancement | |
| after reboot in auto start base. | Emancement | |
| Added some customization requirements. | Enhancement | 2.2.5.0 |
| Fixed the problem that the intersection | | 2.2.3.0 |
| method may be incorrectly calculated and | Bug Fix | |
| plotted when using some road data. | | |
| Optimized the rule of reading files when | Bug Fix | |
| importing data. | | |
| Fixed the problem that file sharing through | Bug Fix | |
| wechat and other tools may fail after data | 205 17 | |

| export. | | |
|--|-------------|---------|
| Modified the default projection of CGCS2000, | | |
| BJ54 predefined coordinate system to 3-degree | Bug Fix | |
| zone. | | |
| Added Israel predefined coordinate system. | Enhancement | |
| Optimized the text display of DXF base map. | Enhancement | |
| Added the function of setting unit when | | |
| importing and exporting DXF. | Enhancement | |
| Increased the import and export of txt format. | Enhancement | |
| Added survey configuration saving logic. | Enhancement | |
| Added support for Rinex 3.04 when connecting | Fahrman | |
| to Oscar. | Enhancement | |
| Added Stop and Go function when connecting | Fahrman | |
| to Oscar. | Enhancement | |
| Added the function of clearing disk and the | | |
| function of debug configuration when | Enhancement | |
| connecting Oscar. | | 2.2.4.0 |
| Solved the problem of startup crash caused by | | - |
| failing to obtain permissions when installing | Bug Fix | |
| software on some Android 8 and 10 phones | | |
| Solved the problem of crash when using some | | - |
| functions on some Android 10 and 11 cell | Bug Fix | |
| phones. | | |
| Fixed the problem of detail point survey | Due fin | |
| program on the text survey interface. | Bug Fix | |
| Fixed the display issues in the survey program | Dug Fix | |
| due to the display configuration. | Bug Fix | |
| Fixed the problem that the positioning icon of | | |
| the stakeout interface is shifted under some | Bug Fix | |

| display resolutions, and optimize the display of release interface and release prompt sound.Fixed the problem of incorrect calculation of the target point in road stakeout after applying base shift.Bug FixFixed the problem of possible jamming when adding antennas.Bug FixAdded building polyline, arc and circle for line stakeout.EnhancementAdded function of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout.EnhancementAdded Grid to Ground tool.Enhancement |
|---|
| Fixed the problem of incorrect calculation of the target point in road stakeout after applying base shift.Bug FixFixed the problem of possible jamming when adding antennas.Bug FixAdded building polyline, arc and circle for line stakeout.Bug FixAdded funtion of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout.Enhancement |
| the target point in road stakeout after applying base shift.Bug FixFixed the problem of possible jamming when adding antennas.Bug FixAdded building polyline, arc and circle for line stakeout.Bug FixAdded funtion of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout.Enhancement |
| base shift. Fixed the problem of possible jamming when adding antennas. Added building polyline, arc and circle for line stakeout. Added funtion of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout. |
| Fixed the problem of possible jamming when adding antennas.Bug FixAdded building polyline, arc and circle for line stakeout.EnhancementAdded function of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout.Enhancement |
| adding antennas.Bug FixAdded building polyline, arc and circle for line stakeout.EnhancementAdded function of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout.Enhancement |
| adding antennas.EnhancementAdded building polyline, arc and circle for line stakeout.EnhancementAdded function of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout.Enhancement |
| stakeout. Enhancement Added funtion of selecting a line for stakeout Enhancement on the DXF base map, optimized function of Enhancement selecting the point for stakeout. Enhancement |
| stakeout. Added funtion of selecting a line for stakeout on the DXF base map, optimized function of selecting the point for stakeout. |
| on the DXF base map, optimized function of Enhancement selecting the point for stakeout. |
| selecting the point for stakeout. |
| |
| Added Grid to Ground tool. |
| |
| Added road stakeout real-time mileage |
| stakeout, optimized the offset display. |
| Added control point survey mode. Enhancement |
| Added Traditional Chinese language option. Enhancement 2.2.3.0 |
| Added Gauss 3-Degree Zone projection. Enhancement |
| Added Columbia Medellin predefined |
| coordinate system, France RGF93 Lambert-93 Enhancement |
| predefined coordinate system. |
| Added support of modifying pole height in |
| tilt-on state. |
| Fixed the issue that the registration status |
| displayed for David may be incorrect. |
| Fixed the issue that importing data of ECEF |
| coordinates may fail. |
| Added length unit support of US feet. Enhancement |
| When creating a new project, added the Enhancement 2.2.2.0 |

| selection portal of plane grid and geoid. | | |
|--|-----------------|--|
| | | |
| Added support for Ireland 35 param | eter | |
| conversion model, add Ireland geoid of | gri Enhancement | |
| format. | | |
| Added support for French geoid of N | | |
| format. | Enhancement | |
| Added the predefined coordinate system | | |
| Philippines. | Enhancement | |
| During connecting with David, added | the | |
| function of decoding and appl | | |
| RTCM1021/1023/1025 when receiving C | ORS | |
| data through the controller network. | | |
| Added function of getting the nearest p | oint | |
| and its mileage on the design road w | hen Enhancement | |
| staking a road. | | |
| Optimized the application after unit sett | ing, | |
| effective for import and export and o | ther Bug Fix | |
| functions. | | |
| Optimized the processing of the devia | tion | |
| between the device positioning and the cer | ntral | |
| meridian of the project, it will no lor | nger Bug Fix | |
| correct the central meridian automatically, | | |
| ask whether to jump to the project parame | ters | |
| interface for manual correct. | | |
| Optimized the interaction of the stake | eout | |
| interface, it automatically obtains 5Hz posi | tion Bug Fix | |
| data refresh frequency when entering stake | | |
| interface. | | |
| Solved the issue that David may crash w | hen Bug Fix | |

| connected by USB in the previous version. | | |
|---|-------------|---------|
| Added photo taking function after point measurement. | Enhancement | |
| Added QR code sharing function for survey point. | Enhancement | |
| Added display and export of ECEF-XYZ coordinate and BLH (Local) coordinate. | Enhancement | |
| Added NCN format import and export, KML/KMZ format import and export. | Enhancement | |
| Added base station point export. | Enhancement | |
| Added the display form of ENh coordinate. | Enhancement | |
| Added simulation connection function. | Enhancement | |
| Added the function of registration by scanning code. | Enhancement | |
| Added function of setting satellite system. | Enhancement | |
| Added Oscar log download function and battery change mode setting. | Enhancement | 2.2.1.0 |
| Added function of automatically connect Oscar when starting software. | Enhancement | |
| Added Oscar internal radio call sign setting function. | Enhancement | |
| Added differential delay threshold limit. | Enhancement | |
| Added display of 2D/3D error in the whole interface. | Enhancement | |
| Added earthwork calculation tool. | Enhancement | |
| Added anglular bisector calculation tool. | Enhancement | |
| Corrected Sweden predefined coordinate system. | Bug Fix | |
| Optimized GSF geoid support. | Bug Fix | |

| Optimized French resources. | Bug Fix | |
|--|-------------|----------|
| Fixed the problem that the coordinates are not refreshed in time between start and stop. | Bug Fix | |
| Added David30 device support. | Enhancement | |
| Added Swedish predefined coordinate system. | Enhancement | |
| Added notice of installing the radio antenna | | |
| when starting up the Oscar internal radio base | Enhancement | |
| mode. | | |
| Fixed the occasional delay in coordinates | | |
| refreshing when connecting with Oscar. | Bug Fix | 2.2.0.0 |
| Updated the display of modulation when | Due Civ | |
| setting the Oscar internal radio mode. | Bug Fix | |
| Fixed the issue that getting the central | | |
| meridian by clicking the button and getting the | Dug Fix | |
| central meridian automatically when | Bug Fix | |
| connecting the device are logically different. | | |
| Added the predefined coordinate system of | Enhancement | |
| Tianjin 2000. | Enhancement | |
| Added the predefined coordinate system of | | |
| Netherlands RDNAP2008, and support for the | Enhancement | |
| ASCII format horizontal grid and vertical grid | Lindicement | |
| under this coordinate system. | | |
| Added the projection parameter setting, the | | 2.1.10.0 |
| button that the central meridian is | Enhancement | |
| automatically obtained according to the | | |
| current position. | | |
| Added the function of survey point editing, | | |
| allowing to modify the point name and | Enhancement | |
| antenna information of the measured point. | | |

| Added the function of checking coordinates via | | |
|--|-------------|---------|
| road mileage. | Enhancement | |
| Added the display of modulation type and | | |
| channel bandwidth when connecting to Oscar | Enhancement | |
| and using the internal radio. | | |
| Added the network link of TCS protocol when | Faboraciat | - |
| connecting with David. | Enhancement | |
| Added the display of the distance from the | Faboracit | - |
| previous survey point in the survey interface. | Enhancement | |
| Added the display of stakeout collection points | Faboraciat | - |
| in the stakeout interface. | Enhancement | |
| When staking out the line to the vertical point, | | - |
| if the vertical point is on the extension line, | Fabaaament | |
| added the drawing display of the extension | Enhancement | |
| line. | | |
| When staking out the line to the stake point, | | |
| added the memory of stake number, and | Enhancement | |
| re-enter line stakeout will continue stakeout | Emancement | |
| according to the stake number before exiting. | | |
| Fixed the problem that the antenna type is | | |
| empty in the survey configuration after Oscar | Bug Fix | |
| is connected via NFC when the software is not | | |
| started. | | |
| Fixed the problem that it will stuck in the | | |
| startup for a long time if there is a network | Rug Eiv | |
| problem when starting the PDA Network | Bug Fix | |
| working mode. | | |
| Added data editing for cross section, super | Enhancement | 2100 |
| elevation, and widening of road module and | | 2.1.9.0 |

| side stakeout function for road stakeout | |
|--|-------------|
| module. | |
| Added the display of vertical point or stake point mileage during line stakeout. | Enhancement |
| Added the distinguishing display of positive and negative offset during line stakeout. | Enhancement |
| Added the predefined coordinate system of | Enhancement |
| Xi'an 80. | |
| Fixed the crash problem after connecting to | |
| Oscar, turning on the static recording and | Bug Fix |
| quickly starting the rover radio mode. | |
| Fixed the crash problem when importing illegal csv files. | Bug Fix |
| Fixed the lagging problem when there are too | |
| many points in the Survey interface. | Bug Fix |
| Fixed the problem that when the threshold of | |
| point stakeout is set too large, clicking the full | Bug Fix |
| image to display will lead a crash. | |
| Fixed the problem that the software still | |
| displays the coordinate and solution status in | |
| the last second of the search when the satellite | Bug Fix |
| is not searching suddenly. | |
| Fixed the problem that the offset may be | |
| calculated incorrectly during the line stakeout. | Bug Fix |
| Fixed the problem that the central meridian is | |
| reset to 0 in Spanish mode. | Bug Fix |
| Fixed the problem that garbled characters are | |
| displayed when opening the exported csv file | Bug Fix |
| in Office Excel by default in Chinese mode. | |

| Added support for Stations Equation, Vertical Profiles and Start Mileage in the road function, and road stakeout performs three-dimensional | Enhancement | |
|---|-------------|---------|
| stakeout of center stake. | | 2.1.8.0 |
| Added support for export in DXF format whose | Enhancement | |
| name or code contains Chinese characters. | | |
| Modified the predefined coordinate system of | Bug Fix | |
| Turkey. | | |
| Road management and road stakeout are | | |
| added to the software. The current version | | |
| supports the editing of Alignment by | | |
| intersection method and element method, | Enhancement | |
| conversion of intersection method to element | Emancement | |
| method, and road stake out function. Other | | |
| functions will be implemented in subsequent | | |
| versions. | | |
| Added Survey with confirmation button to the | | |
| survey configuration. After turning if off, the | Fahrmann | |
| survey point data will be saved directly without | Enhancement | 2.1.7.0 |
| confirmation box. | | |
| Added the display of QZSS satellites in the sky | | • |
| map and satellite table. | Enhancement | |
| Software optimization: retain the user's | | |
| common configuration habits; SNR is adjusted | | |
| to CN0; Portuguese pre-defined coordinate | Enhancement | |
| system name adjustment. | | |
| Fixed the crash issue of clicking the offset point | | - |
| tool to enter the point library to select the | Bug Fix | |
| point when the project is not opened. | | |

| Fixed the crash issue of switching to Turkish to | | |
|--|-------------|---------|
| perform point survey. | Bug Fix | |
| The Chinese version of the software is | | |
| renamed to "Tianshuo Measurement", and the | Enhancement | |
| Chinese display is optimized in the software. | | |
| Added the function of rotating the map view | | |
| when staking out, check this function in the | Enhancement | |
| display config interface of staking out. | | |
| Added the function of importing points to the | | |
| survey point library from coordinate files; add | | |
| the function of importing points to the control | Enhancement | |
| point library or the stakeout point library from | | |
| DXF, SHP, SIMA files. | | |
| Added the L value negative input and | Fabaaamont | |
| calculation in the offset point from line tool. | Enhancement | 2.1.6.0 |
| Optimized Bulgarian display. | Enhancement | |
| Fixed the problem that the software automatic | | |
| calculates the UTM number incorrectly when it | Bug Fix | |
| is located in the Western Hemisphere. | | |
| Fixed the problem that mtext is not displayed | Due Civ | |
| when importing some DXF basemaps. | Bug Fix | |
| Fixed the problem that prompy might not be | | |
| correct when selecting forward and backward | Bug Fix | |
| stakeout prompt type. | | |
| Fixed the problem that when the tilt function is | | |
| turned on, the rover mode is stopped and the | Bug Fix | |
| coordinates are no longer refreshed. | | |
| Support DXF import as the base map, and add | Enhancement | |
| function of selecting points on the DXF base | Enhancement | 2.1.5.0 |

| map to the staking point library. | | |
|--|-------------|---------|
| Add the export of the collected line when | | |
| exporting DXF. | Enhancement | |
| | | |
| Support SIMA format import with empty | | |
| elevation data, add the encoding setting when | Enhancement | |
| selecting SIMA import and export, to avoid the | | |
| situation of garble code. | | |
| When connecting with Oscar, it can be chosen | | |
| to shut down the Oscar receiver at the same | Enhancement | |
| time when exiting Nuwa app. | | |
| When configuring David at base mode, add the | Enhancement | |
| 'save config' statement. | | |
| When performing point stakeout and line | | |
| stakeout, add the search function for staking | Enhancement | |
| point and staking line. | | |
| Add the checkbox 'Display All Staking Point' in | | |
| the display config of the point stakeout | Enhancement | |
| interface. | | |
| Adjust part of the statement display for | | |
| English, Chinese, Japanese, and Greek. | Enhancement | |
| Add predefined Mexican coordinate system. | Enhancement | |
| Solve the crash of selecting empty project as | | |
| the source project if there is no project in the | Bug Fix | |
| | | |
| app. | | |
| Added Bulgarian displayed. | Enhancement | |
| Added Irish pre-defined coordinate systems. | Enhancement | |
| Fixed the problem of low success rate of David | Bug Fix | 2.1.4.0 |
| connection. | - | |
| Fixed a crash of the tilt enable button when | Bug Fix | |

| connecting with Oscar Ultimate, if the Android | | |
|---|--|---------|
| phones do not support GIF view. | | |
| Fixed the problem that when connecting Oscar | | |
| Ultimate and turning on the tilt enable, and | Bug Fix | |
| then switching to connect David, the tilt | Dug Tix | |
| button was still on. | | |
| Fixed the crash of clicking the confirm button | | |
| on ths soft keyboard on TC20 after modifying | Bug Fix | |
| the point name in stakeout. | | |
| Added tilting initialization instructions, | | |
| optimize tilting interaction, and add tilting | F . b . c . c . b . c | |
| initialization, measurement and lofting | Enhancement | |
| instructions in user manual. | | |
| Added Malaysia RSO projection. | Enhancement | |
| Added Offset Point From Line in the Offset | | |
| Point tool, to determine the Point on the | Fabra and and | |
| extension Line or the Point after Offset on the | Enhancement | |
| extension Line. | | |
| Added the elevation difference, slope ratio and | | 2420 |
| so on the calculation results in the Azimuth | Enhancement | 2.1.3.0 |
| Distance tool. | | |
| Added the Greek display in Nuwa. | Enhancement | |
| Added Slovenia predefined coordinate system. | Enhancement | |
| Added Morocco predefined coordinate system. | Enhancement | |
| Added Belgium predefined coordinate system. | Enhancement | |
| Added Netherlands predefined coordinate | E.L. | |
| system. | Enhancement | |
| Added Guatemala predefined coordinate | E.L. | |
| system. | Enhancement | |
| | 1 | 1 |

| Added Columbia predefined coordinate system. | Enhancement | |
|---|-------------|---------|
| Added Austria predefined coordinate system. | Enhancement | |
| Solved the problem that when connecting with | | |
| David, the parameters of compass could not be | Pug Eiv | |
| read, and the stakeout indicating arrow was | Bug Fix | |
| invalid. | | |
| Solved the problem that the DXF file exported | | |
| by Nuwa may can't be imported into autocad. | Bug Fix | |
| Solved the problem that coordinates may not | | |
| be refreshed after tilt off. | Bug Fix | |
| Fixed the problem of parameter calculation or | | |
| point correction, in which the error details of | Bug Fix | |
| each pair of points cannot be seen. | | |
| Optimized Japanese display. | Bug Fix | |
| Optimized Spanish display. | Bug Fix | |
| The input control is optimized. A one-click | | |
| clear button is added to the input box. The | | |
| latitude and longitude input box supports | Enhancement | |
| intelligent input and real-time format | | |
| switching. | | |
| Added CGCS2000 predefined default | Enhancement | |
| coordinate system. | Linancement | 2.1.0.9 |
| In the connection interface the Bluetooth | Enhancement | |
| name and MAC address display in newline. | Linancement | |
| When connecting Oscar receiver and setting | | |
| the base station mode, added CMR and RTD | Enhancement | |
| differential formats. | | |
| When connecting Oscar receiver and setting | Enhancement | |

| static, added configuration record duration, and add recorded duration display.Image: configuration display.When connecting Oscar receiver and setting the built-in network base station mode, added Ntrip protocol support.EnhancementWhen connecting Oscar receiver, added NMEA serial output configuration.EnhancementWhen connecting Oscar receiver, added disk usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdded the size of the point name on the Survey interface.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point to distinguish it from general Detail points and added the property of distance from the target point.Bug FixFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | | |
|---|--|-------------|
| When connecting Oscar receiver and setting the built-in network base station mode, added Ntrip protocol support.EnhancementWhen connecting Oscar receiver, added NMEA serial output configuration.EnhancementWhen connecting Oscar receiver, added disk usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point"EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | static, added configuration record duration, | |
| the built-in network base station mode, added Ntrip protocol support.EnhancementWhen connecting Oscar receiver, added NMEA serial output configuration.EnhancementWhen connecting Oscar receiver, added disk usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point" to distinguish it from general Detail points and added the property of distance from the target point.Bug FixFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFCC connection.Bug Fix | and add recorded duration display. | |
| Ntrip protocol support.Image: Construction of the problem of using the layer name as the poplem of using the layer name as the poplem of low success rate of NFC connection.Image: Construction of NFC construction.Ntrip protocol support.Ntrip protocol support.EnhancementWhen connecting Oscar receiver, added disk usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection pointEnhancementdiving stakeout to "Stakeout collection point"Enhancementfixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | When connecting Oscar receiver and setting | |
| When connecting Oscar receiver, added NMEA serial output configuration.EnhancementWhen connecting Oscar receiver, added disk usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point" to distinguish it from general Detail points and added the property of distance from the target point.Bug FixFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | the built-in network base station mode, added | Enhancement |
| serial output configuration.Enhancementwhen connecting Oscar receiver, added disk usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection pointEnhancementdiving stakeout to "Stakeout collection point"EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | Ntrip protocol support. | |
| serial output configuration.Image of the point of the point name on the size of the point name on the Survey interface.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection pointEnhancementduring stakeout to "Stakeout collection point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | When connecting Oscar receiver, added NMEA | Fabaaament |
| usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point" to distinguish it from general Detail points and added the property of distance from the target point.Bug FixFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | serial output configuration. | Enhancement |
| usage display and remaining capacity display.EnhancementAdded heading display when connected to David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point' to distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | When connecting Oscar receiver, added disk | Fabracast |
| David plus.EnhancementAdjusted the size of the point name on the Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point to distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | usage display and remaining capacity display. | Ennancement |
| David plus.Image: constraint of the point name on the survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection pointEnhancementduring stakeout to "Stakeout collection point"Enhancementadded the property of distance from the targetEnhancementpoint.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | Added heading display when connected to | Fabaaamant |
| Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point" to distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | David plus. | Enhancement |
| Survey interface.EnhancementAdded SHP basemap import function.EnhancementAdded satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point" to distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed other import - SHP import failure issues.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | Adjusted the size of the point name on the | Enhancoment |
| Added satellite map display on the online map of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point" to distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | Survey interface. | Enhancement |
| of Survey interface.EnhancementAdded the function of stakeout to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection point during stakeout to "Stakeout collection point" to distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | Added SHP basemap import function. | Enhancement |
| of Survey interface.Image: Constraint of Stake out to the vertical point on the line for Line stakeout.EnhancementModified the point type of the collection pointImage: Constraint of Stakeout collection pointImage: Constraint of Stakeout collection pointduring stakeout to "Stakeout collection point"Image: Constraint of Stakeout collection pointImage: Constraint of Stakeout collection pointto distinguish it from general Detail points and added the property of distance from the target point.Image: Constraint of Constraint of Stakeout collection pointFixed the problem of using the layer name as the point name in other import - DXF import.Image: Bug FixFixed the problem of low success rate of NFC connection.Image: Bug Fix | Added satellite map display on the online map | Enhancoment |
| point on the line for Line stakeout.EnhancementModified the point type of the collection point | of Survey interface. | Emancement |
| point on the line for Line stakeout.Image: Constant of the collection pointModified the point type of the collection pointImage: Constant of the collection pointduring stakeout to "Stakeout collection point"Image: Constant of the collection pointto distinguish it from general Detail points and added the property of distance from the target point.Image: Constant of the collection pointFixed the problem of using the layer name as the point name in other import - DXF import.Image: Bug FixFixed other import - SHP import failure issues.Image: Bug FixFixed the problem of low success rate of NFC connection.Image: Bug Fix | Added the function of stakeout to the vertical | Enhancoment |
| during stakeout to "Stakeout collection point"Enhancementto distinguish it from general Detail points and added the property of distance from the target point.EnhancementFixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed other import - SHP import failure issues.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | point on the line for Line stakeout. | Enhancement |
| to distinguish it from general Detail points and added the property of distance from the target point. Enhancement point. Bug Fix Fixed the problem of using the layer name as the point name in other import - DXF import. Fixed other import - SHP import failure issues. Bug Fix Fixed the problem of low success rate of NFC connection. Bug Fix | Modified the point type of the collection point | |
| added the property of distance from the target point. Fixed the problem of using the layer name as the point name in other import - DXF import. Fixed other import - SHP import failure issues. Fixed the problem of low success rate of NFC connection. | during stakeout to "Stakeout collection point" | |
| point.Fixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed other import - SHP import failure issues.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | to distinguish it from general Detail points and | Enhancement |
| Fixed the problem of using the layer name as the point name in other import - DXF import.Bug FixFixed other import - SHP import failure issues.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | added the property of distance from the target | |
| the point name in other import - DXF import.Bug FixFixed other import - SHP import failure issues.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | point. | |
| the point name in other import - DXF import.Fixed other import - SHP import failure issues.Bug FixFixed the problem of low success rate of NFC connection.Bug Fix | Fixed the problem of using the layer name as | Βιισ Είχ |
| Fixed the problem of low success rate of NFC Bug Fix | the point name in other import - DXF import. | |
| connection. Bug Fix | Fixed other import - SHP import failure issues. | Bug Fix |
| connection. | Fixed the problem of low success rate of NFC | Bug Fix |
| Fixed the problem of displaying registration Bug Fix | connection. | |
| | Fixed the problem of displaying registration | Bug Fix |

| information error when connecting | | |
|--|-------------|---------|
| unregistered Oscar receivers. | | |
| Fixed the problem that the base coordinates of the collection point are incorrect when | Bug Fix | |
| switching between network 1 + 1 mode and VRS mode. | | |
| Organized Chinese and Japanese translations in the app. | Bug Fix | |
| Added the function of the plane grid. | Enhancement | |
| Added the support of GRD, GSF, OSGB plane grid or geoid. | Enhancement | |
| Added the function of online download plane grid or geoid. | Enhancement | |
| Added the import and export of SIMA format files. | Enhancement | |
| When inputting the repeated line name to continue the Linework measurement, it is supported to choose from the start point or the end point. | Enhancement | 2.1.0.8 |
| Redo the line stakeout function. Stakeout to the point on the line according to the interval and the offset. | Enhancement | |
| Added the report file function in detail point survey, turn on the function and the coordinate of every epoch will be saved into a .txt file. | Enhancement | |
| Added the display of L5 SNR. | Enhancement | |
| Added button to cancel the display of electronic bubble. | Enhancement | |

| Added the stakeout pointing arrow text description. | Enhancement | |
|---|-------------|---------|
| Solved the crash problem when opening the Survey interface on some phones with higher display resolution. | Bug Fix | |
| The height value in the location share function is calculated to the coordinates of ground points according to the antenna settings in Nuwa. | Bug Fix | |
| Added Molodensky Badekas datum transform model. | Enhancement | |
| Added Singapore predifined coordinate system SVY21. | Enhancement | |
| Added Australia predifined coordinate system GDA2020. | Enhancement | |
| Optimized the Survey interface, the survey button will change automatically and the survey configuration will change according to the selection of Survey Mode(Detail or Continous). | Enhancement | 2.1.0.6 |
| Optimized the Survey Config interface, the HRMS limited value and VRMS limited value will change according to the Solution Limited. | Enhancement | |
| Display optimization of the Survey Config interface. The Config in the Survey and the Stakeout function module only displays relevant items; all configuration items are retained in the Survey Config. | Enhancement | |
| Adjusted the longitude and latitude | Enhancement | |

| coordinates display, put N, S, E, W after the | |
|---|-------------|
| number. | |
| Opened to use TCS through PDA Network in | |
| Oscar base configuration. | Enhancement |
| Added the function of Oscar registration by | |
| Nuwa. | Enhancement |
| Added the limit to 5 survey points when | |
| connecting to general instruments of NMEA | Enhancement |
| mode. | |
| Corrected some translation errors in English | |
| language. | Bug Fix |
| Solved the problem that sometimes the | |
| number of satellites used is larger than the | Bug Fix |
| number of visible satellites. | |
| Solved the problem of software exception if | Bug Fix |
| click Device Info during NFC connection. | Bug Tix |
| Solved the problem of Nuwa software crash | |
| when connecting Oscar via NFC, if Nuwa is not | Bug Fix |
| provided system permission. | |
| Solved the problem in XML export that the | Bug Fix |
| solution state of all survey points are fixed. | |
| Solved the problem when repeated using the | |
| baseshift, the value of Base shift and the actual | Bug Fix |
| coordinate shift are not the same. | |
| Solved the problem that the survey points in | |
| the Survey interface may not be displayed | Bug Fix |
| when the Survey Style is Detail. | |
| Solved the problem that the point cannot be | Bug Fix |
| selected to stakeout when importing NE points | |

| to the Stakeout point library. | | |
|---|-------------|---------|
| Solved the problem of Nuwa crash for some android 9.0 models. | Bug Fix | |
| Adjusted the display of Tilt Angle quality, Tilt direction quality and Heading quality in tilt measurement. | Bug Fix | |
| Adjusted the algorithm for calculating the Distance to base, the incorrect result can be avoided by calculating according to the XYZ coordinate in the case of projection unselected. | Bug Fix | |
| Changed the tone frequency of stakeout prompt distance(long) from 5s to 2s at a time. | Bug Fix | |
| Fixed the crash when connecting devices using Android 9 caused by the API level change. | Bug Fix | |
| Fixed the problems that Nuwa is unable to obtain HTTP permissions using Android 9 caused by the API level change, including inablity to perform software automatic update and online map display. | Bug Fix | 2.1.0.5 |
| Added moving direction indicator arrow in stakeout interface. | Enhancement | |
| Added the circle display whose radius is equal to the prompt tone distance in stakeout interface. | Enhancement | 2.1.0.3 |
| The prompt tone in different grades in stakeout interface. When the surveyor is approaching to the point to stake out, Nuwa beeps every 5 seconds. When the surveyor | Enhancement | |

| arrives at the point to stake out, Nuwa beeps every 1 second. Added the XML format export which supports being imported to EZSurv to post process Enhancement Stop&Go data. |
|---|
| Added the XML format export which supports being imported to EZSurv to post process Enhancement Stop&Go data. |
| being imported to EZSurv to post process Enhancement Stop&Go data. |
| Stop&Go data. |
| |
| |
| Adjusted DXF export, add height coordinate |
| and height annotation. Distinguish layers Enhancement |
| according to different kinds of annotations and |
| point feature property. |
| Added GNSS Linework function. The survey |
| line will be displayed in survey interface. The |
| survey line allows operations such as delete |
| point, insert point, and continue surveying. |
| Change the API level to 28 and re-launch on |
| Google Play. Bug Fix |
| Fixed the issue that the point coordinate saved |
| to the Point database may be wrong in the Bug Fix |
| case of the Base Shift. |
| Fixed incomplete import Stakeout Point |
| selecting all from Survey Point. |
| Fixed the crash issue when turning on location |
| share function for some android devices. |
| Tilt compensation function is available for |
| Oscar Ultimate model. |
| Added elevation stakeout for point stakeout Enhancement |
| and line stakeout. |
| Opened the TCP Client function for the Enhancement |
| receiver network. |
| Solved the problem that conversion from NEh Bug Fix |

| to BLH may be incorrect when there are seven | | |
|--|-------------|---------|
| parameters. | | |
| Solved the problem that selecting the coordinate system from the Coord System List is not effective when editing the project parameters. | Bug Fix | |
| Solved the crash problem caused by the name containing illegal characters when creating a new project. | Bug Fix | |
| After setting the latitude and longitude format to DD:MM.MMM, the number of decimal places is changed to 7 digits. | Bug Fix | |
| Solved the problem that the link and differential delay are not displayed on the survey interface when Oscar is set as the receiver network rover mode. | Bug Fix | |
| Solved the problem that the debug button in the device info interface sometimes is opened illegally when switching from connecting David to connecting Oscar. | Bug Fix | |
| Corrected the English expression of the altitude and geodetic height on the survey interface. | Bug Fix | |
| Corrected the English expression of long press to cancel the Bluetooth match on the connection interface. | Bug Fix | |
| The display of base point coordinates is changed to ground when base antenna height is obtained. | Enhancement | 2.0.1.4 |

| The display of north / east direction STD is | | |
|--|---------------------|---------|
| added to the survey point attribute which is | Enhancement | |
| allowed to be exported. | | |
| During the point survey process, it is allowed | Enhancement | |
| to stop the survey by pressing the stop button. | Linancement | |
| Fixed the issue that after configuring David by | | |
| Nuwa to stop the base mode, restarting David | Bug Fix | |
| it still displays as Base. | | |
| Fixed the probabilistic crash issue of returning | | |
| to the main interface after completing the | Bug Fix | |
| point staking. | | |
| Open Oscar Reset function | Enhancement | |
| The Collection End time of points in the point | | |
| library will change with the software time zone | Enhancement | |
| setting | | |
| The project list is arranged in reverse | F . I | |
| chronological order by edit time | Enhancement | |
| Fixed crash caused by choosing an empty | | |
| coordinate system | Bug Fix | |
| Fixed the probabilistic crash in NFC connection | Bug Fix | 2012 |
| Fixed the probabilistic crash of setting Ntrip | | 2.0.1.2 |
| server after Oscar connection | Bug Fix | |
| Fixed failure of setting up TCPClient in | | |
| connecting David | Bug Fix | |
| Solved the problem that modifying antenna | | |
| parameters does not take effect after the | Bug Fix | |
| survey of smooth points is completed | | |
| Solved the problem that Base points would not | | |
| increase after reaching 9 | Bug Fix | |
| | | |

| Fixed HTML export crash when there are stakepoints | Bug Fix | |
|---|-------------|---------|
| Solved the problem that the export Collection End time property has no hour, minute, or second, when the separator is a space in custom export | Bug Fix | |
| Solved the problem that the searched results for the point library based on time is empty | Bug Fix | |
| Fix the severe problem that modification of Ant Height is not effective in the Survey Config | Bug Fix | 2.0.0.9 |
| Supports new model Oscar | Enhancement | |
| Added display of base shift, datum transition, plane adjustment and height fitting in the interface of Satellite Info - Position | Enhancement | |
| For data import, it supports data preview before importing data | Enhancement | |
| For data export, it added HTML export | Enhancement | |
| Custom import and export format support editing, viewing and deleting | Enhancement | |
| Added related tips in the Bluetooth pairing and device connection interface | Enhancement | 2.0.0.8 |
| The base supports RTCM3.0 format | Enhancement | |
| The logic of Detailed Point acquisition is modified to pop up confirmation dialogue after the acquisition is completed | Enhancement | |
| Added threshold distance setting for stakeout tone | Enhancement | |
| In the survey configuration - Display configuration interface, added the check box of | Enhancement | |

| displaying all stake out points | | |
|--|-------------|---------|
| Solve the flashback problem of Nuwa in landscape orientation display | Bug Fix | |
| Unify NEh coordinates and RMS data, retain 4 decimal places | Bug Fix | |
| Solve the application crash caused by the special registration date in the Demo Key | Bug Fix | |
| Solve the problem of incomplete display of part of the Spanish interfaces | Bug Fix | |
| Solve the problem that the seven parameters and the correction parameters are not imported into the project parameters in the newly created project | Bug Fix | |
| Solve the problem of search failure according to time in point library search | Bug Fix | |
| Solve the problem that exporting the custom interface cannot slide | Bug Fix | |
| Solve the problem that in the survey interface the speed is not refreshed | Bug Fix | |
| Adjust default antenna | Bug Fix | |
| Added Japanese JGD2011 coordinate system | Enhancement | 1007 |
| Optimized the stakeout prompt message | Enhancement | 1.0.9.7 |
| Fixed the problem of wrong name for the Portugal coordinate system | Bug Fix | |
| Fixed the problem of inaccurate acquisition time during the point collection | Bug Fix | 1.0.9.5 |
| Optimized the SHP export coordinate format | Enhancement | |
| Optimized online upgrade information prompts | Enhancement | |

| Optimized Tools Offset Point calculation | Enhancement | |
|---|--------------|---------|
| Optimized Tools Azimuth and Intersection | Enhancement | |
| Angle calculation | | |
| Optimized OSM online map loading | Enhancement | |
| Optimized the seven parameters calculation | Enhancement | |
| Optimized Survey Config options | Enhancement | |
| Optimized the function of adding stakeout | Enhancement | |
| points and control points | | |
| Added Ghana's predefined coordinate system | Enhancement | |
| Added Portuguese predefined coordinate system | Enhancement | |
| Optimized static storage | Enhancement | |
| Optimized elevation fitting calculation | Enhancement | |
| Fixed elevation problems caused by geoid | Bug Fix | |
| model during data inverse calculation | Dug Tix | |
| Fixed the flashback issue caused in certain | Bug Fix | |
| situations | bug Tix | 1.0.8.0 |
| Optimize DXF export | Enhancement | |
| Fixed the problem that the default is the | | |
| control point library when importing points for | Bug Fix | |
| stakeout point library | | |
| Fixed the problem that the interface has no | | |
| prompt when the stakeout point is | Bug Fix | |
| approaching the stakeout point library | | |
| Support collecting points with physical | Enhangenerst | |
| collection button in TC20 controller | Enhancement | |
| Support quick points collecting in 'point | | 1.0.4.1 |
| stakeout' and 'line stakeout' with physical | Enhancement | |
| collection button | | |

| Add 'survey hotkey' in point survey configuration page | Enhancement | |
|---|-------------|---------|
| Fix average collection problem if the solution can't meet the requirements | Bug Fix | |
| Change the display of coordinate axis in projection parameters as X->North Y->East | Enhancement | |
| Optimized the calculation of parameters and the secondary calculation process of point correction | Enhancement | |
| Optimized the device connection experience | Enhancement | |
| Optimized the device registration experience | Enhancement | 1.0.3.3 |
| Optimized antenna management | Enhancement | 1.0.5.5 |
| In the survey configuration, the survey epoch is changed to be editable by users | Enhancement | |
| Added Oscar preview in Device Connection, so stay tuned! ! | Enhancement | |
| Added support for common NMEA devices | Enhancement | |
| Added the function of automatically zooming the scale when approaching the stakeout point during point stakeout/line stakeout | Enhancement | |
| Added multi-point selection function when importing stakeout points | Enhancement | |
| Solved the connection stability of NtripClient function under Spanish and other languages | Enhancement | 1.0.3.2 |
| Added the functions of Device Debug and static mutual exclusion | Enhancement | |
| Fixed the display problem when NtripClient and TCPClient are connected | Bug Fix | |
| Modified the GNSS point coordinates displayed | Enhancement | |

| in the base shift as BLH | | |
|--|-------------|---------|
| Optimized static record Station ID setting function | Enhancement | |
| Fixed crash when switching languages in Spanish and other languages | Bug Fix | |
| Combined the mount point and rover configuration to solve the problem of the display of the mount point history data | Enhancement | |
| Fixed the problem that the collection time epoch does not take effect in the survey configuration | Bug Fix | |
| Fixed the problem of not displaying NEh coordinates when manually starting the base station | Bug Fix | |
| Fixed the problem that the base point cannot be selected in the base shift | Bug Fix | |
| Fix the stakeout point error on the map and coordinates error after the base shift | Bug Fix | |
| Fixed the error of multiple repetitive calculations in the base shift | Bug Fix | |
| Added support for north-south/east-west hemisphere | Enhancement | |
| Optimize continuous point survey by distance | Enhancement | |
| Optimize continuous point survey by time | Enhancement | |
| Add the predefined coordinate systems of Malaysia and Romania | Enhancement | 1.0.2.9 |
| Add the function of station-id setting during static measurement | Enhancement | |
| Add the function of Inner RTK control | Enhancement | |

| Add the function of importing projects | Enhancement | |
|--|-------------|---------|
| Add preview function for predefined coordinate system | Enhancement | |
| | | |
| Optimize the arrangement and display of | Enhancement | |
| countries or regions in the predefined | Emancement | |
| coordinate systems | | |
| Optimize the display of satellite quantity | Enhancement | |
| Optimize the display of antenna height interface | Enhancement | |
| 'Connected' at the top of the main interface | E da su si | |
| is changed to 'Connected' | Enhancement | |
| The position status of satellite interface for | | |
| base station is changed to 'Base Manual' and | Enhancement | |
| 'Base Auto' | | |
| Fix the problem of not displaying NEh | | |
| coordinates when manually starting the base | Bug Fix | |
| station | | |
| Add new projections: Cassini, Oblique | | |
| Stereographic Alternative, Stereographic, and | Enhancement | |
| Transverse Cylindrical Equal Area | | |
| Fix the problem of imported line files are not | | |
| identified | Bug Fix | |
| Fix the problem of crashing when creating new | | |
| projects and point survey under Spanish | Bug Fix | |
| language | | |
| Optimize database upgrade | Enhancement | |
| | Enhancement | |
| Add predefined coordinate system | | 400 |
| Modify the satellite quantity display as 'satellite tracked / satellite used' | Bug Fix | 1.0.2.8 |

| Optimize the export format of dxf file | Enhancement | |
|--|-------------|---------|
| Fix the problem that the elevation increases | | |
| when manually starting the base station | Bug Fix | |
| Optimize base shift experience | Enhancement | |
| Change shp/dxf export coordinates to local | | |
| coordinates | Enhancement | |
| Fix the problem that satellites on the Sat Tab | | |
| interface has always shown true | Bug Fix | |
| Add differential data format display when | Enhancement | |
| using Ntrip to obtain source list | Linancement | |
| Optimize system stability | Enhancement | |
| System compatibility is improved, compatible | Enhancement | |
| with upgrades on older software | | |
| Fixed the problem that the antenna height | | |
| disappeared in the device connection interface | Bug Fix | |
| after reloading the software | | |
| Fixed the problem of the invalidity of static | Bug Fix | |
| survey after canceling auto-start | bug Tix | |
| Fixed the problem of the Ntrip Client set up | Bug Fix | |
| failure for the rover | | |
| Fixed the problem of the antenna height | Bug Fix | 1.0.2.6 |
| configuration failure for the rover | bug Tix | 1.0.2.0 |
| Optimize the software automatic update | Enhancement | |
| experience | Linancement | |
| Optimize the device connections | Enhancement | |
| Optimize continuous acquisition by time | Enhancement | |
| Add Geoid Model: (1) support EGM96 and | | |
| EGM08 at the same time; (2) optimize data | Enhancement | |
| loading and reduce waiting time for different | | |

| devices; (3) simplify algorithm calculation | | |
|---|-------------|---------|
| process and save system resources | | |
| Add UTM projection support for the southern hemisphere | Enhancement | |
| Optimize the rules for point acquisition automatic naming | Enhancement | |
| Optimize the base shift function: (1) support | | - |
| multiple times of base shift; (2) support | | |
| real-time modification of the shift parameters; | Enhancement | |
| (3) reorganize the base shift logic; (4) redesign | | |
| the base shift UI | | |
| Optimize the solution state of the data export, | Enhancement | |
| which is the same as the board definition | Linancement | |
| Optimize the display of the antenna height | Enhancement | |
| when manual-starting the base station | | |
| Repair of other problems | Enhancement | |
| Antenna height display optimization | Enhancement | |
| Survey configuration: display configuration optimization | Enhancement | |
| Re-enter static storage, status optimization | Enhancement | |
| Static storage antenna optimization when | Enhancement | |
| self-starting the base station | | |
| Line stakeout 'distance' distinguishes between | Enhancement | 1.0.2.4 |
| positive and negative | | |
| Add column name for coordinate export | Enhancement | |
| Remove the 'Acquisition Status' of the 'Text | Enhancement | |
| Acquisition' interface | | |
| 'Smoothing' and 'Acquisition' are combined | Enhancement | |
| Ntrip site management: IP address display is | Bug Fix | |

| incomplete | | |
|--|-------------|---------|
| Click base/rover configuration without changing order | Enhancement | |
| Support for name modification of base/rover configuration User-defined name can be changed, the system default name cannot be changed | Enhancement | |
| Add reminder when creating a new project | Enhancement | |
| Change the logic of antenna type choosing, the antenna type must be choosing before connection | Enhancement | |
| Change the default antenna height as pole height in surveying, change the default antenna height as slant height in static surveying | Enhancement | |
| Support choosing file type in import file | Enhancement | |
| Add GPS mock location | Enhancement | |
| Fixed the error of configuration when build a new project | Bug Fix | 1.0.2.3 |
| Optimized the interface freeze if there are too many points in point survey interface | Enhancement | |
| Optimized the display of export interface | Enhancement | |
| Optimized the display of the result in two point intersection | Enhancement | |
| Optimized the display of title bar | Enhancement | |
| Optimized the option logic in import interface | Enhancement | |
| Change the voice output frequency in point stakeout | Enhancement | |
| Add RTCM1230 message in base model | Enhancement | |

| | T | |
|--|-------------|---------|
| Fixed software crashed when sharing project | Bug Fix | |
| Optimized the logic to register David | Enhancement | |
| Optimized the device connection | Enhancement | |
| Support auto start static mode | Enhancement | |
| Add xyz apporoximate in rinex file | Enhancement | |
| Optimized the speed to log in CORS. | Enhancement | |
| Add point name and code in dxf format | Enhancement | |
| Fix the abnormity H value if the antenna slant height is zero | Bug Fix | |
| Change the 'Projection' to 'CRS' | Enhancement | 1.0.2.2 |
| Change the threshold value in collect points by distance | Enhancement | |
| Optimized auto collect function by distance | Enhancement | |
| Optimized software access authority (it need location information authority at the same time when using Bluetooth if your android version is higher than Android 6.0) | Enhancement | |
| Optimized auto update function | Enhancement | 1.0.2.1 |
| Optimized the display of system language | Enhancement | |
| Optimized many default value | Enhancement | |
| Optimized the pop-up message when getting the first fixed solution | Enhancement | |
| Optimized the language of pop-up messages | Enhancement | |
| Fixed the display error in height fitting title panel | Bug Fix | |
| Default to open update auto test function | Enhancement | 1.0.2.0 |
| Fixed software crash due to the display of decimal point in some language | Bug Fix | 1.0.2.0 |
| Optimized the display of project information | Enhancement | |
| | | |

| Fixed the bug that the QR code can't refresh when project parameters changed | Bug Fix | |
|--|---------|--|
| Fixed the title can't be changed with system language changed | Bug Fix | |
| Fixed numeric keypad have no decimal point problem in some cellphone | Bug Fix | |
| Fixed the unusual local coordinate value under some ellipsoid | Bug Fix | |